

**SMEG DIGITAL ELECTRONIC PROGRAMMER
(6 BUTTONS)**

HOW TO USE THE CLOCK



TO SET THE TIME:

Button 1 commences on the left.

- Press buttons 2 & 3 at the same time
- Keep buttons 2 & 3 pressed in, also press either button 4 or 5 to set the time
- Release all buttons – the time is set

TO SET THE MINUTE MINDER:

- Press button 1, keep this pressed in and press button 4 or 5 to set the timer duration
- Release the buttons
- To cancel the minute minder, press button 1 and button 4 to minus the time
- To clear the alarm when it sounds, press button 1

TO SET AUTOMATIC COOKING:

- Press button 3, keep this button pressed in.
- Press buttons 4 & 5 to set the length of time you want to cook for
- Wait 6 seconds
- Press button 2, keep this button pressed in
- Press buttons 4 or 5 to select the time you want to end cooking
- Select the oven function you want to use
- Select the temperature
- To cancel the programme and return to manual cooking, press button 6