

FOR INFORMATION ONLY

HOW TO REMOVE THE SHELF SAFETY FITTINGS




To stop damage during transit, the shelves are supplied with safety fittings.

Slide the fitting to the front of the shelf.



Lift the shelf at the rear and slide forward



You can now remove the fitting and reposition the shelf.



Shelf Safety Spacer