



SMEG DUSF44X BRACKET INSTALLATION GUIDE



Front Bracket

Bottom Bracket



This bracket is attached to the sides of the cabinet with the holes lining up with the 6 fixing points on the front of the oven.



The holes on the bottom bracket face towards the cabinet and are attached by the supplied screws. The plain side supports the oven weight.