

FOR INFORMATION ONLY


RANGE - Dishwasher, Cooker, Hob, Oven, Washer Dryers

PART - Heating Element


FUNCTION - Dependant on the appliance it is installed in, the heating element is responsible for providing heat to cook food, heat water, dry clothes etc.



Washer Dryer element



Hob element



Cooker / Oven element



Cooker / Oven element



Dishwasher element



Dishwasher element

Parts are available from

www.smeg-service.co.uk/smegshop