



## FOR INFORMATION ONLY

### SI4642D, SI4642B, SI4742D & SI4642D Demo Mode info.

The demo mode instruction is missing from the current user manuals.

#### Demo mode

Press and hold the Slider-position 0 and Pause-key together for a few seconds. A short beep signalizes the detection of the correct keys.



After the delay a "dE" is shown on the timer display. Now the demo mode is active. Deactivation of demo mode is done in the same way, the "dE" is shown during the delay and fades out after the delay was over.

