



How to replace a freezer door on a Smeg Fab28 fridge.

First remove the 2 screws on the hinged side of the door while supporting the door at the same time.



Remove the door when the hinge is free, replace with new door and secure hinge with the 2 screws.

If the latch clip needs to be replaced, remove the 2 screws shown and replace with new latch clip.





Freezer Door Assembly



Freezer Door Latch Clip



Freezer Door Hinge

Parts are available from

www.smeg-service.co.uk/smegshop